

Directions for Front Lifted Truck Bracket

Supplied Hardware: 12-Stainless Steel (SS) 1/4 x 20 x 1 bolts; 18- (SS) washers; 6-SS flange nuts; 6-(SS) Locking Nuts; 8-(SS) self tapping screws; 2- aluminum brackets

NOTE: *As you progress with the install, check that the mudflap remains square and plumb to the tire.*

Step 1. PARK VEHICLE ON LEVEL GROUND.

Step 2: Un package your new brackets and mudflaps. Smooth side of mudflap is the rear side. If applicable, Stainless Steel weights face rearwards.

Step 3. Align the bracket on the fender well lip to be centered to your tires. Once it is straight, attach the bracket to the fendewell with a clamp.

It may be necessary to put a curve in the bracket to match the curve of the wheel well.

If your tires are out more than 2-3" beyond the fenderwell, the bracket may not be able to be aligned to the tire. The mudflap may be shifted when installed to line up with the tire tread.

Step 4. Drill one hole through the bracket and wheel well lip at the upper outside corner. Drill a starter hole first with a 1/8" bit, then drill the final hole with a 1/4" bit. Attach the bracket with one bolt thru the washer, bracket and fender well, using the flange nut for attachment. Leave the bolt hand tight for now.

NOTE: You may use the self tapping screws instead of the bolts in areas not accessible for attaching the flange nuts.

Step 6. Place a level on the top edge of the bracket and adjust for horizontal plumb. If you are not on level ground, you may need to line up the bracket by sight.

Step 7. Drill a second hole in the bottom outside edge of the mudflap and wheel well lip and secure with a second bolt.

Step 8. Install the 3rd bolt, evenly spaced between the top and bottom bolts, and tighten all bolts.

Step 9. Clamp the mudflap to the bracket and adjust the position in and out to be centered . If the mudflap needs to be extended beyond the edge of the bracket, you should place the radiused edge on the outside. If the mudflap is going to line up with the edge of the bracket, use the straight corner on the outside.

Step10. Attach the mudflap to the bracket with the SS bolts, locking nuts and washers on both sides.

NOTE: Recheck bolts and screws monthly and retighten if necessary.

